

# Allworx Telephone System Training

## Setting up a Mailbox:

- Press the **MESSAGES** key twice
- Enter your PIN code and press the **#** key (default PIN code is 1234)
- Press **4** to setup mailbox
- Press **2** to record name (to include user in directory listing)
- Press **3** to record greetings (record greeting 0, other greetings optional)
- Press **5** to change PIN code (this should have been done on your first login)

## To make outgoing call:

- Pick up the handset
- Dial **9** to begin your dialing *or* press an available **LINE** key

## To dial an internal station or User:

- Press a **Station** key for the person you are calling *or* press an **Ext 1xx** key and dial their 3 digit station number

## To answer a call:

- While the phone is ringing, pick up the handset
- Press **SPEAKER** or flashing **LINE** key to receive the call

## Placing a call On Hold

- Press the **HOLD** key
- To reconnect to the call, press the **LINE** that is flashing. Hold will allow other users to pick up the call

### Transferring Calls:

- Press **TRANSFER**
- Press a programmed button or dial the station number to receive the call
- When they answer, you can make an announcement if needed
- Hang up to complete the transfer

### Transferring calls to Voicemail:

- Press **TRANSFER**
- Press the **VMAIL** soft key
- Press a programmed button or dial the station number of the mailbox to receive caller

### To Voice announce to another Station:

- Press the upper **INTERCOM** key
- Dial the station or User number
- speak directly to the party, they do not need to pick up handset

### Call Pickup:

- Dial **7**
- Dial the 3 digit station number of the ringing phone you want to intercept

### Conference Calls:

- Place your active call on **HOLD**
- Press an available **LINE** key or dial **9** and the external number
- When the party answers press **CONF**
- Press the call that was placed on hold (flashing green only **LINE** key)

### Do Not Disturb:

- While phone is idle, press the **MUTE/DND** key, light will turn amber.
- To remove Do Not Disturb, press the **MUTE/DND** again.
- Note: Phone will still be able to place calls while in DND mode.

## Checking voicemail from another telephone

- From any office phone, dial **6**
- Dial the station number for the vm you would like to check
- Enter the PIN code
  
- From outside the office, dial your main number
- Dial **6** when the system answers
- Dial the station number for the vm you would like to check
- Enter the PIN code

## Leaving a Message in another users mailbox

- Dial **3**
- Dial the mailbox number you wish to leave a message in
- To skip the personal greeting, press **#**

## Hot Desk

- Press **CONFIG**
- Scroll down to Hot Desk Login
- Enter your Station number
- Enter your PIN code