

COMDIAL DX80, TADIRAN AND MOBICEL TELEPHONE TIME CHANGE

1. FROM ANY OFFICE TELEPHONE.
2. PRESS **FEATURE # *** AND ENTER IN YOUR PASSWORD.
(DEFAULT PASSWORD #####)
3. PRESS **SHOW** AND ENTER **0814**.
4. PRESS **SAVE** THEN **SHOW**.
5. THE OPTION TO CHANGE THE **YEAR** WILL APPEAR. IF YOU DO NOT NEED TO CHANGE THE YEAR, PRESS **NEXT**. IF YOU NEED TO CHANGE THIS VALUE, PRESS **CHG**, ENTER IN TWO DIGITS FOR THE YEAR AND PRESS **SAVE** THEN **NEXT**.
6. THE OPTION TO CHANGE THE **MONTH** WILL APPEAR. IF YOU DO NOT NEED TO CHANGE THE MONTH, PRESS **NEXT**. IF YOU NEED TO CHANGE THIS VALUE, PRESS **CHG**, ENTER IN TWO DIGITS FOR THE MONTH AND PRESS **SAVE** THEN **NEXT**.
7. THE OPTION TO CHANGE THE **DAY** WILL APPEAR. IF YOU DO NOT NEED TO CHANGE THE DATE, PRESS **NEXT**. IF YOU NEED TO CHANGE THIS VALUE, PRESS **CHG**, ENTER IN TWO DIGITS FOR THE DATE AND PRESS **SAVE** THEN **NEXT**.
8. THE OPTION TO CHANGE THE **WEEKDAY** WILL APPEAR. IF YOU DO NOT NEED TO CHANGE THE WEEKDAY, PRESS **NEXT**. IF YOU NEED TO CHANGE THIS VALUE, PRESS **CHG**, TO SELECT THE WEEKDAY, AND PRESS **SAVE** THEN **NEXT**.
9. THE OPTION TO CHANGE THE **HOUR** WILL APPEAR. PRESS **CHG** AND ENTER IN TWO DIGITS FOR THE HOUR IN MILITARY FORMAT AND PRESS **SAVE** THEN **NEXT**.
10. THE OPTION TO CHANGE THE **MINUTES** WILL APPEAR. PRESS **CHG** AND ENTER IN TWO DIGITS FOR THE MINUTES AND PRESS **SAVE**.
11. PRESS THE **ON/OFF** BUTTON TO TAKE THE TELEPHONE OUT OF PROGRAMING MODE.