

PARNTER TELEPHONE SYSTEMS TIME CHANGE

(PROGRAMING MUST BE DONE FROM THE ADMINISTRATOR TELEPHONE)

TO UPDATE THE TIME:

1. WITH THE HANDSET IN THE CRADLE OF YOUR TELEPHONE, PRESS THE FEATURE KEY.
2. PRESS 0 TWICE. (0,0).
3. PRESS SYSTEM PROGRAM TWICE. (USE THE LEFT INTERCOM KEY IF YOU DO NOT HAVE A SYSTEM PROGRAM KEY).
4. PRESS #103.
5. ENTER THE TIME IN 24-HOUR NOTATION (HHMM).
6. EXIT PROGRAMMING MODE. (FEATURE 00)

TO UPDATE THE DATE:

1. WITH THE HANDSET IN THE CRADLE OF YOUR TELEPHONE, PRESS THE FEATURE KEY.
2. PRESS 0 TWICE. (0,0).
3. PRESS SYSTEM PROGRAM TWICE. (USE THE LEFT INTERCOM KEY IF YOU DO NOT HAVE A SYSTEM PROGRAM KEY).
4. PRESS #101.
5. ENTER THE MONTH, DAY AND YEAR. (MMDDYY).
6. EXIT PROGRAMMING MODE. (FEATURE 00)