

TOSHIBA TELEPHONE TIME CHANGE

(PROGRAMING MUST BE DONE FROM THE ADMINISTRATOR TELEPHONE STATION 200 BY DEFAULT)

TO SET DATE:

1. WITH THE HANDSET IN THE CRADLE OF YOUR TELEPHONE, PRESS THE INTERCOM KEY+651.
2. ENTER THE DATE (YYMMDD).
3. PRESS REDIAL. YOU WILL HEAR THE CONFIRMATION TONE.
4. PRESS SPEAKER. PHONE WILL RETURN TO IDLE MODE.

TO SET TIME:

1. WITH THE HANDSET IN THE CRADLE OF YOUR TELEPHONE, PRESS THE INTERCOM KEY+652.
2. ENTER THE TIME (HHMMSS).
3. PRESS REDIAL. YOU WILL HEAR THE CONFIRMATION TONE.
4. PRESS SPEAKER. PHONE WILL RETURN TO IDLE MODE.

TO SET DAY OF WEEK:

1. WITH THE HANDSET IN THE CRADLE OF YOUR TELEPHONE, PRESS THE INTERCOM KEY+653.
2. ENTER THE NUMBER WHICH CORRESPONDS WITH THE APPROPRIATE DAY OF THE WEEK. 1 = SUNDAY, 2 = MONDAY, 3 = TUESDAY, ETC.
3. PRESS REDIAL. YOU WILL HEAR THE CONFIRMATION TONE.
4. PRESS SPEAKER. PHONE WILL RETURN TO IDLE MODE.